

INSTALLATION INSTRUCTIONS

# Gustafs Panel System

WALL



**1** Mount the battens with the help of a laser.



**2** Adjust the battens with the help of spacers.



**3** \*Installing the insulation.



**4** Setting out the first Capax onto battens.



**5** Remove any dust or filings from the Capax.



**6** Ensure that the panels sit properly in the Capax system.



**7** Mounting a connecting profile.



**8** Installing the next panel.



**9** Installing the floor list.

CEILING



**1** Measure and indicate hanger



**2** Hang up main runner profile



**3** Connect main runners.



**4** Fasten distance profile



**5** Secure snap lock with selfdrilling



**6** Install panels.



**7** \*Install mineral wool insulation.



**8** Dust off panels.

*\* Please note that the fire classification for perforated panels only is valid if mineral wool insulation is used behind Gustafs Panels. The mineral wool should be 45 mm thick, density 28 kg/m<sup>3</sup> and have Euroclass A1 or A2.*

For installation instructions in Polish, Spanish, French, Swedish and German, visit [www.gustafs.com](http://www.gustafs.com)

